


SHIFT BEZEL REMOVAL/INSTALLATION


id091700606800

1. To prevent scratches or damage, affix protective tape to the position shown in the figure.




ac3wzw00002842

2. Insert a remover tool into the position shown in the figure, move it in the directions of the arrows and detach the clips from the shift panel.



ac3wzw00004368

3. Pull the shift bezel in the direction of the arrow shown in the figure, detach the clips from the shift panel and remove the shift bezel.



ac3wz00002844

4. Install in the reverse order of removal.